




User Manual

Wi-Fi Digital Photo Frame

Cautions

Precautions and Maintenance

- For indoor use only.
- To avoid risk of the fire or electric shock, do not expose the unit to moisture or condensation
- To avoid overheating, do not block the ventilation holes on the back of the digital photo frame.
- Keep the digital photo frame out of direct sunlight.
- Do not dismantle the digital photo frame. There is a risk of electric shock and there are no user-serviceable parts inside. Dismantling the digital photo frame will void your warranty.

Clean the LCD Screen

- Treat the screen carefully. Because the screen of the digital photo frame is made of glass and it would be broken or scratched easily.
- If fingerprints or dust accumulate on the LCD screen, we recommend using a soft, non-abrasive cloth such as a camera lens cloth to clean the LCD screen.
- Moisten the cleaning cloth with the cleaning solution and apply the cloth to the screen.

Cautions

WARNING:

To reduce the risk of electric shock, do not expose the unit to rain or excessive moisture.

This device is intended for private use and not suitable for commercial use!

Introduction

Congratulations on your Vphoto download. We are excited to share your enjoy moment. We are always looking to improve and evolve our products, new features will be downloaded automatically to your device or mobile app, and you'll be notified by Email ,push notifications, and in-app messages.

Contents

2. Getting Started	05
2.1 Activate the Digital Frame	05
2.2 Download the Application & Create an Account	06
3. Operation Instruction	08
3.1 Send Blessing	08
3.2 Upload Photos and Video	10
3.3 Email Sharing & Send Photos and Video	11
3.4 Import Photos & Videos via TF Card/USB Drive	13
3.5 Slideshow Display	15
3.6 Add to Favorites & Create Albums	18
3.7 Oil Painting Gallery	20
3.8 AI Image Studio	21
3.9 Weather	24
3.10 Clock	25
3.11 Alarm	26
3.12 Pomodoro Timer	27

Contents

4. Settings	29
4.1 Photos	29
4.2 Settings	30
4.3 User Management	35
4.4. Power	35
5. Technical Specification & Features	36
6. Troubleshooting Guide	38
7. Warranty & Customer Support	40
8. Firmware Upgrade Instructions	41

Digital Photo Frame Overview


10.1" WiFi Frame Features

- | | | |
|-----------------------|----------------|---------|
| ① Touch Screen | ⑤ Bracket | ⑨ USB |
| ② Frame | ⑥ Loudspeaker | ⑩ DC IN |
| ③ Power On/Off Button | ⑦ TF Card Slot | |
| ④ Wall Mount Hole | ⑧ TYPE-C | |

Features:

- ① Support 2.4G WIFI
- ② Built-in Memory: 16GB

Digital Photo Frame Overview




2. Getting Started


2.1 Activate the Digital Frame

(1) Selecting language.

Please select the language you want




(2) Connecting to Wi-Fi.



2. Getting Started

(3) Setting up your frame.

First you can select city, then select time zone, and finally enter a nickname for your device.




2.2 Download the Application & Create an Account

(1) Downloading the VPhoto APP.

① Search for [VPhoto] on the Google Play/App Store to download the App.

2. Getting Started

② Scan QR code to download the App.




(2) New Device or Cloud Backup Restoration

① Log in as new device:
Set up this device as a brand-new, empty device.
No previous data will be transferred.

② Restore from cloud backup:
Restore photos, alarms, and other data from your old device.
Previous settings and content will be carried over to this one.

Then you can share photos or videos to the frame.





3. Operation Instruction

3.1 Send Blessing

Follow these steps to create and send blessing

(1) Tap the 

Open the Vphoto app and tap the  to enter the greeting card feature.



3.Operation Instruction

(2)Type Your Message

Enter your heartfelt wishes in the text box.

(3)Choose a Display Effect

Select an eye-catching display effect to enhance your greeting card.20 types effect for selection.

(4)Set Display Mode


Decide how the greeting will be displayed, either manually or automatically.

(5)Schedule the Sending Time

Choose to send it immediately or set a specific time for delivery.

(6)Select Recipient

Choose the target device or recipient for your greeting.



(2) (3)

(4) (5)


(6)

3.Operation Instruction

3.2 Upload Photos & Video

(1)Select a photo and click "Next step" to send.

(2)Then you can successfully transfer to the photo frame.




3.Operation Instruction

3.3 Email Sharing & Send Photos and Video


(1) Click the settings module.



(2) Then click on the "+" symbol.




(3) Enter your Email Address , then click "confirm"




3.Operation Instruction

(4) Your Email will receive an email from: P2YHS@waophoto.com.



(5) Click on the email address to send pictures or videos.





(6) The photo or video you send will be displayed in the frame.

3.Operation Instruction

3.4 Import Photos & Videos via TF Card/USB Drive


How to Share Photos&Videos Via TF Card or USB Drive

- (1) Insert the USB Drive or TF card into the frame.
(2) Click  then click "Manage Photos" and "Import Photos".




3.Operation Instruction

- (3) Select the files to get copied.
(4) Click the Copy icon , then click OK to import selected files to the internal storage.



(3)




(4)

3.Operation Instruction

3.5 Slideshow Display

Menu

Tap the pic to show the menu to set up.Only support to check the photo&video after transfer.



(1) Rotation:Manually rotate the picture 90°clockwise.

(2) Single/Loop

Single: Plays a single image or video once and stops.

Loop: Continuously repeats the playback of images or videos in the selected sequence.

(3) Delete: Delete the selected file.

(4) Fill to Frame/Fit to Frame

Fill to Frame: The image completely fills the screen without any borders (some content may be cropped).

Fit to Frame: The image is displayed in its original aspect ratio, fully visible within the screen.

(5) Full-screen: The image automatically pans left and right to display the entire content.

3.Operation Instruction

(6) Hide: Hide the selected photos or video that you don't want to show.



(7) Edit Photo

Click on "Edit Photo".

Click on the text editing symbol and enter the text.

Adjust the position of the image to be cropped.

Click on the check mark to complete cutting and editing.



(8) Click "Settings"

① Set the photo display mode:

·Title


·Slide interval

·Display mode


·Slide transition effects

3.Operation Instruction

- ② Click Details can open or close image description
- ③ Slideshow interval optional: 3s/5s/15s/30s/ 1m/5m/10m/15m/30m/1h/12h/24h
- ④ Slide transition effects: Default/Gradient/Rotation/Cube/ Accordion/Zoom Fade Out/Zoom Center/Zoom/Random



(9) Details: View detailed information such as photo memory and upload time.



3.Operation Instruction

(10) Add Favorite:

- ①Click on "Favorites"
- ②Click the  in the upper left corner to enter the gallery.
- ③Find your favorite folder.
- ④Show your favorite pictures.



3.6 Add to Favorites & Create Albums

(1)Favorites Feature

Easily organize your favorite photos using the "Favorites" feature for quick viewing and sharing.


- ① Access Gallery
Go to the “Photos” section and click “Everything” in the left sidebar to display all photos and videos.
- ② Open Full Screen
Select the photo you want and click it to enter full-screen view.
- ③ Add to Favorites

Tap anywhere on the photo to show the function menu, then click the Favorites icon to add it to your “Favorites” list.



3.Operation Instruction

Try out this feature to create your personalized collection of favorite memories!



(2) Create a Album

Effortlessly organize and categorize your photos and videos using the album management feature for easier access and storage.

① Create Album

Tap the “+” icon, enter a custom name, and confirm to create the album.

② Go to Favorites

Open the Favorites folder to view your liked photos.



③ Select Photos

Tap the  in the top right, then choose the photos you want.

3.Operation Instruction


④ Add to Album

Tap the  in the top right, select your custom folder, and the photos are added successfully.




3.7 Oil Painting Gallery

Follow these steps to send Oil Painting



3.Operation Instruction

- (1) Tap the “Oil Painting”
- (2) Choose an oil painting
- (3) Click the  to display oil paintings on the equipment



(1) (2)


(3)

3.8 AI Image Studio


- 1.Filter:Photo styles available: Cyberpunk, Pixel, Illustration, Pixar, Watercolor, Neon, B&W Film.
- 2.Beautify:AI beautification, HD enhancement, and old photo restoration for uploaded images.
- 3.Stickers: Add stickers to the picture: glasses, lightning, pipe

3.Operation Instruction

- 4.AI Retouch:Apply style and prompts to photos for desired effects, with multiple aspect ratio options.
- 5.AI video Gen:Based on the selected style and prompt words, the AI generates videos from the uploaded photos.
- 6.AI Record:The preservation of records generated by AI functions




3.Operation Instruction



3.Operation Instruction

3.9 Weather

- (1) Go to “Settings” > “General Settings”.
- (2) Scroll down to “Set the weather” and tap it.
- (3) Click “+ Add City”, Type in the city name, and search for the corresponding city.
- (4) Display weather information.



3.Operation Instruction

3.10 Clock


(1) Click the clock module.




(2) Click the settings icon in the upper right corner.



(3) Swipe to select your preferred style.



(4)Click "Set as watch face" to apply the new watch face. Click "Preview" to view it while keeping your current one.




3.Operation Instruction

3.11 Alarm



(1) Click the Alarm module.



(2) Click “ go set it ” or to add alarm.



(3) Add Alarm:Enter into the "Add Alarm" page to set alarm title, adjust alarm time, select ringtone, set alarm volume, configure repeat days, set alarm duration, enable and configure snooze function.




3.Operation Instruction

3.12 Pomodoro Timer

(1) Enter the Pomodoro Timer function from the main interface.

- ① Tap the Pomodoro button in the upper-left area to start the default 25-minute Focus Time.
- ② You can tap Pause to suspend ongoing timing. Press the back key to quit the session as needed.




(2) Use the general timing function.

- ① Tap the Timing button in the upper-right area to activate the countdown function.
- ② Tap Pause anytime to suspend the ongoing timing process.
- ③ Tap Count to finish the current timing session and save the record automatically.

3.Operation Instruction

- ④ Press the back key if you need to exit the timing page.




(3) Set fixed or customized countdown duration.

- ① Select preset durations: 1min, 3min, 5min, 10min, 15min, 30min, 45min, 60min to start a quick countdown.
- ② Tap More to customize your desired countdown duration.

4.Settings

4.1 Photos


- (1) ? :View Supported Storage formats.
- (2) ≡ :Hide the left function bar to full view image plate.
- (3) Photo/Video: Choose to view only photos or videos.
- (4) ⋮ :Click the ⋮ icon to sort or delete photos or videos.
- (5) Everything: Show all album information.
- (6) Internal Storage : Store pictures&videos in internal storage.
- (7) SD Card: Store pictures and videos via SD Card.
- (8) USB: Store pictures and videos via USB.
- (9) Album:Click Add Box to add album.
- (10) Favorites: Mark as favorite pictures or videos.
- (11) User Name: Display user name list.




4.Settings

4.2 Settings

- (1) My picture frame: Enter "My picture frame" to show the Device Info(Connection Code&QR code) and User Management. Click each user account to view photos&videos shared by the corresponding user, you can choose to edit the username, delete user accounts or photos.




- (2) General Settings:Enter into the "General Settings" to adjust brightness and volume,set touch sounds,select language,modify font size, configure date & time,schedule sleep mode, set motion sensor and auto-rotate screen.




4.Settings

(3) Photo settings: Enter into the "Photo settings" page to set slideshow mode, define photo sorting rules, toggle the display of photo titles, weather information and time information.




(4) Wallpaper: Enter "Wallpaper" to change standby background, select built-in wallpapers, and set display styles for the screen.




4.Settings

(5) Manage photos: Enter into the "Manage Photos" to show the Photo storage, viewing the memory storage information, You can add photos to Favorites or hide/import/export photos or play from external storage, ect.




(6) Transmission: Follow the connection tutorial to connect the frame to your PC via USB cable for photo transfer.




4.Settings

(7) WLAN: Click Wi-Fi to connect to the Internet




(8) Help: "Help" provides Q&A to help you quickly answer your questions and “Guide” gives instructions on how to quickly start using the frame.




4.Settings

(9) Backup Recovery: Backup Recovery allows you to backup external devices or delete all photos before resetting the photo frame. The device automatically restarts once finish the operation.




(10) About: In About, view device details, including memory usage, system version, ect.



4.Settings

4.3 User Management

The connection QR code and user management can be displayed. Click each user account below, you can choose to edit the username,delete user accounts or photos.To add a new user,click the plus button.



4.4 Power:Tap to shut down or reboot the device.

5. Technical Specification & Features

Technical Specifications & Features(Touch screen and non-touch screen models)					
Display	9.7" (4:3)	10.1"(16:10)	15"(4:3)	15.6" (16:9)	16.2"(4:3)
Resolution	768*1024IPS Panel	280*800 New IPS Panel	1024*768IPS Panel	1920*1080IPS Panel	1258*930 IPS Panel
Built-in Memory	32GB	32GB	32GB	32GB	32GB
Built-in WIFI	2.4GWIFI	2.4GWIFI	2.4GWIFI	2.4G+5G Dual WIFI	2.4G+5G Dual WIFI
Adapter	DC5V/2A	DC5V/2A	DC12V/1.5A	DC12V/1.5A	DC12V/2A
Main Function	Picture+Music+Movie+Calendar+Clock Online+Memory+ FHD1080P+ Wifi Cloud+Weather Station + Remote Control+ IPS Panel+32GB Memory+ Auto-Rotate+ 2ways Rotation+can be used as	Picture +Music +Movie+ Calendar+ Clock+ Memory +Motion sensor + Weather station+ Full HD Movie + Cloud WIFI + 32GB built-in memory+Remote control	Picture +Music +Movie+ Calendar+ Clock+ Memory +Motion sensor + Weather station+ Full HD Movie + Cloud WIFI + 32GB built- inmemory+Remote Control	Picture +Music +Movie+ Calendar+ Clock+ Memory +Motion sensor + Weather station+ Full HD Movie + Cloud WIFI + 32GB inmemory+Remote	Picture+Music+Movie+ Calendar+Clock Online+Memory+ FHD1080P+ Wifi Cloud+Weather Station +Remote Control+Touch Screen+ IPS Panel+32GB Memory+ Auto-Rotate+ 2ways Rotation+can be used
Accessories	Use Manual, Bracket, Adapter +Remote Control	Use Manual, Bracket, Adapter,Remote Control	Use Manual, Bracket, Adapter+Remote Control	Use Manual, Bracket, Adapter+ Remote Control	Use Manual, Bracket, Adapter,Remote Control
USB Port	USB2.0&Type-C				
Languages	OSD Language & Multiple Language Options				
Working Temperature	0C~40C,Humidity:10-85%				
Software	In-house R&D Software Vphoto APP Supported by World Famous Cloud System				

5. Technical Specification & Features

Technical Specifications & Features(Touch screen and non-touch screen models)				
Display	17"(5:4)	19"(4:3)	21.5" (16:9)	32" (16:9)
Resolution	1280*960 IPS Panel	1280*960 IPS Panel	1920*1080 IPS Panel	1080Pixels New IPS
Built-in Memory	32GB	64GB	32GB	64GB
Built-in WIFI	2.4G+5G Dual WiFi	2.4G+5G Dual WiFi	2.4G+5G Dual WiFi	2.4G+5G Dual WiFi
Adapter	DC12V/2A	DC 12V/3A	DC 12V/3A	DC19V/3.15A
Main Function	Picture +Music +Movie+ Calendar+ Clock+ Memory +Motion sensor + Weather station+ Full HD Movie + Cloud WIFI + 32GB built-in memory+Remote Control	Music+Movie+Calendar+Clock Online +Remote Control + Light sensor +64GB Memory + Auto-Rotate + Projection Screen function	Music+Movie+Calendar+Clock Online +Remote Control + Light sensor +32GB Memory + Auto-Rotate + Projection Screen function	Picture +Music +Movie+ Calendar+ Clock+ Memory + Weather station+ Full HD Movie + Cloud WIFI + 32GB built-in memory+Remote Control
Accessories	Use Manual, Bracket, Adapter,Remote Control	Use Manual, Adapter, Wall Amount Accessories,	Use Manual, Adapter, Wall Amount Accessories,	Use Manual, Bracket, Adapter,Remote Control
USB Port	USB2.0&TYPE-C			
Languages	OSD Language & Multiple Language OptionsOSD			
Working Temperature	0C~40°C,Humidity:10-85%			
Software	In-house R&D Software Vphoto APP Supported by World Famous Cloud System			

6. Troubleshooting Guide

6.1 FAQ

1.Q:Can I send photos to the frame remotely?

A:Yes. With WiFi connectivity and a VPHOTO app, you can send photos directly from your smartphone to the frame, even when you are far away. It is a convenient way to share daily moments with family members.

2.Q:Does the frame need to stay connected to my phone all the time?

A:No. After photos are uploaded to the frame, they can usually be viewed without keeping your phone connected. Your phone is only needed when you want to send new photos or manage content remotely.

3.Q:How many photos can a 10.1-inch digital photo frame store?

A:This 10.1-inch WIFI photo frame include built-in storage that can hold thousands of photos, allowing you to keep years of memories in one place.

4.Q:Can multiple family members send photos to the same frame?

A:Yes. This WiFi digital photo frame allow multiple users to connect through the app, so family members and friends can share photos and keep the frame updated together.

5.Q:Does the frame automatically rotate photos?

A:Yes. This photo frame support Auto-Rote Screen, allowing photos to display correctly whether the frame is placed horizontally or vertically.

6.Q:Is the setup process complicated?

A:No. Setup is usually simple: connect the frame to WiFi, download the app, connect your device, and start uploading photos. Most users can complete the setup within a few minutes.

7.Q:Can I use it as a gift?

A:Yes. A 10.1-inch digital photo frame is a popular gift choice for parents, grandparents, couples, and friends. It is especially meaningful because you can preload family memories or continue sending new photos after gifting.

6.Troubleshooting Guide

8.Q:Can I delete or manage photos directly from the frame?

A:Yes. Most 10.1-inch digital photo frames allow you to manage your photos directly through the touchscreen. You can delete unwanted pictures on the Manage photos page.

9.Q:Can I add captions to my photos?

A:Many WiFi digital photo frames support adding captions when uploading photos through the app. This makes each picture more meaningful by adding dates, greetings, or personal notes.

10.Q:Can I control the slideshow speed?

A:Yes. You can usually adjust how long each photo stays on the screen, allowing you to create a relaxing slideshow or a faster photo rotation experience.

7. Warranty & Customer Support

Warranty

Our warranty is 12 months from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or "warranty void" sticker has been removed or altered on the product.

This warranty does not cover :

- 1)Appearance damage or artificial damage.
- 2)Accident, misuse, abuse, negligence or modification of any part of the product
- 3)Damage due to improper operation or maintenance, connection to improper equipment or attempted repair by anyone else, not from us.

Contact Us


For any inquiries and after-sales service requirements , or product user experience feedback, please feel free to contact us.

Email:Service@comesourcing.com


8. Firmware Upgrade Instructions

App Software Version Upgrade Guide

1. Android OS: Download the latest version from Google Play
- ①Open Google Play on your phone.
 - ②Tap the search bar, enter "Vphoto" and search.
 - ③Tap the Download or Update button.



2. iOS OS:Download the latest version from Apple Store
- ①Open Apple Store on your phone.
 - ②Tap the search bar, enter "Vphoto" and search.
 - ③Tap the Download or Update button.




8.Firmware Upgrade Instructions

Device's Software Version Upgrade Guide

1. Manual Update

- ①Tap "Settings" to enter the Settings page
- ②Tap on "About"
- ③Tap on the Version number to check for updates



2. Automatic Updates

- ①Tap "Settings" to enter the Settings page
- ②Tap on "About"
- ③Open the Automatic Updates button

